

CTC MACHINE IOMBX LAYOUT - 3

10/1/10

CT (2)

H6				
CARD	PORT	PIN	PB	FUNCTION
DOUT32 CARD 2	D	D7	5-1	Left Indicator Light 4L
		D6	5-2	Center Indicator Light 4
		D5	5-3	Right Indicator 4R
		D4	5-4	Left Indicator Light 6L
		D3	5-5	Center Indicator Light 6
		D2	5-6	Right Indicator 6R
		D1	4-1	Normal Indicator Light Switch 3
		D0	4-2	Reverse Indicator Light Switch 3
	C	C7	4-3	Normal Indicator Light Switch 5
		C6	4-4	Reverse Indicator Light Switch 5
		C5	5-7	Left Indicator Light 8L
		C4	5-8	Center Indicator Light 8
		C3	5-9	Right Indicator 8R
		C2	5-10	Left Indicator Light 10L
		C1	5-11	Center Indicator Light 10
		C0	5-12	Right Indicator 10R
	B	B7	5-13	Left Indicator Light 14L
		B6	5-14	Center Indicator Light 14
		B5	5-15	Right Indicator 14R
		B4	5-16	Left Indicator Light 16L
		B3	5-17	Center Indicator Light 16
		B2	5-18	Right Indicator 16R
		B1	4-5	Normal Indicator Light Switch 7
		B0	4-6	Reverse Indicator Light Switch 7
A	A7	4-7	Normal Indicator Light Switch 9	
	A6	4-8	Reverse Indicator Light Switch 9	
	A5	5-19	Left Indicator Light 18L	
	A4	5-20	Center Indicator Light 18	
	A3	5-21	Right Indicator 18R	
	A2	5-22	Left Indicator Light 20L	
	A1	5-23	Center Indicator Light 20	
	A0	5-24	Right Indicator 20R	

H7				
CARD	PORT	PIN	PB	FUNCTION
DOUT32 CARD 3	D	D7	5-25	Left Indicator Light 24L
		D6	5-26	Center Indicator Light 24
		D5	5-27	Right Indicator 24R
		D4	5-28	Left Indicator Light 26L
		D3	5-29	Center Indicator Light 26
		D2	5-30	Right Indicator 26
		D1	4-9	Normal Indicator Light Switch 13
		D0	4-10	Reverse Indicator Light Switch 13
	C	C7	4-11	Normal Indicator Light Switch 15
		C6	4-12	Reverse Indicator Light Switch 15
		C5	5-41	Left Indicator Light 28L
		C4	5-42	Center Indicator Light 28
		C3	5-43	Right Indicator Light 28R
		C2	5-44	Left Indicator Light 30L
		C1	5-45	Center Indicator Light 30
		C0	5-46	Right Indicator Light 30R
	B	B7	5-47	Left Indicator Light 32L
		B6	5-48	Center Indicator Light 32
		B5	5-49	Right Indicator Light 32R
		B4	4-32	Right Indicator Light 38R
		B3	4-33	Center Indicator Light 38
		B2	4-34	Left Indicator Light 38L
		B1	4-13	Normal Indicator Light Switch 17
		B0	4-14	Reverse Indicator Light Switch 17
A	A7	4-15	Normal Indicator Light Switch 19	
	A6	4-16	Reverse Indicator Light Switch 19	
	A5	4-35	Right Indicator Light 36R	
	A4	4-36	Center Indicator Light 36	
	A3	4-37	Left Indicator Light 36L	
	A2	4-38	Right Indicator Light 34R	
	A1	4-39	Center Indicator Light 34	
	A0	4-40	Left Indicator Light 34L	



CARD ADDRESS 4



CARD ADDRESS 5