

# CTC MACHINE IOMBX LAYOUT - 4

10/1/10

CT (2)

H8				
CARD	PORT	PIN	PB	FUNCTION
<b>DOUT32 CARD 4</b>	D	D7	4-43	Right Indicator Light 44R
		D6	4-44	Center Indicator Light 44
		D5	4-45	Left Indicator Light 44L
		D4	4-46	Right Indicator Light 42R
		D3	4-47	Center Indicator Light 42
		D2	4-48	Left Indicator Light 42
		D1	4-17	Normal Indicator Light Switch 23
		D0	4-18	Reverse Indicator Light Switch 23
		C	C7	4-19
	C6		4-20	Reverse Indicator Light Switch 25
	C5		4-31	Left Indicator Light 40L
	C4		4-49	Center Indicator Light 40
	C3		4-50	Right Indicator Light 40R
	C2		5-31	Code Light Under 16
	C1		4-21	Normal Indicator Light Switch 27
	C0		4-22	Reverse Indicator Light Switch 27
	B	B7	4-23	Normal Indicator Light Switch 31
		B6	4-24	Reverse Indicator Light Switch 31
		B5	4-25	Normal Indicator Light Switch 33
		B4	4-26	Reverse Indicator Light Switch 33
		B3	4-27	Normal Indicator Light Switch 35
		B2	4-28	Reverse Indicator Light Switch 35
		B1	4-29	Normal Indicator Light Switch 37
		B0	4-30	Reverse Indicator Light Switch 37
	A	A7	4-41	Normal Indicator Light Switch 43
		A6	4-42	Reverse Indicator Light Switch 43
		A5	5-32	Code Light Under 14
		A4	5-33	Code Light Under 10
		A3	5-34	Code Light Under 8
		A2	5-35	Code Light Under 6
		A1	5-36	Code Light Under 4
		A0	5-50	Code Light Under 18

H9				
CARD	PORT	PIN	PB	FUNCTION
<b>DIN32 CARD 2</b>	D	D7	7-1	Right Signal Lever 4
		D6	7-2	Left Signal Lever 4
		D5	7-3	Right Signal Lever 6
		D4	7-4	Left Signal Lever 6
		D3	7-5	Right Signal Lever 8
		D2	7-6	Left Signal Lever 8
		D1	7-7	Right Signal Lever 10
		D0	7-8	Left Signal Lever 10
		C	C7	7-9
	C6		7-10	Left Signal Lever 14
	C5		7-11	Right Signal Lever 16
	C4		7-12	Left Signal Lever 16
	C3		7-13	Right Signal Lever 18
	C2		7-14	Left Signal Lever 18
	C1		7-15	Right Signal Lever 20
	C0		7-16	Left Signal Lever 20
	B	B7	7-17	Right Signal Lever 24
		B6	7-18	Left Signal Lever 24
		B5	7-19	Right Signal Lever 26
		B4	7-20	Left Signal Lever 26
		B3	7-21	Right Signal Lever 28
		B2	7-22	Left Signal Lever 28
		B1	7-23	Right Signal Lever 30
		B0	7-24	Left Signal Lever 30
	A	A7	7-25	Right Signal Lever 32
		A6	7-26	Left Signal Lever 32
		A5	7-27	Right Signal Lever 34
		A4	7-28	Left Signal Lever 34
		A3	7-29	Right Signal Lever 36
		A2	7-30	Left Signal Lever 36
		A1	7-31	Code Button Under 26
		A0	7-32	Code Button Under 24



CARD ADDRESS 6



CARD ADDRESS 7